

The Ball Joint Super Set allows for the removal and installation of pressfit ball joints such as ball joints, universal joints and truck brake anchor pins.

- Used to remove and install press fit ball joints
- C-frame tool can be used alone to remove and replace universal joints
- Impact rated. No higher than 1/2" Dr. impact wrench
- Comes complete in durable case

197 Ball Joint Super Set



Package Type: Blow Molded Case

Dimensions: 27" x 14" x 6"

Warranty: Lifetime vs. Mfg Defect

UPC: 047084001974

Applications:

- GM® and Ford® light-duty trucks, vans, and SUVs through 2003
- Dodge® light trucks through 1998
- Dodge® vans, Durango, and Dakota through 2003
- Honda® Accord, Civic, del Sol, and Prelude through 2001

