



**84200**

**7 PC Oxygen Sensor Socket Set**

This set provides an easy method to remove and install various sensors, sending unit, vacuum switches and Injectors on most domestic and import vehicles. Offset sockets are comprised of SAE and Metric sized sockets, to be used with 3/8" or 1/2" Drive ratchet and breaker bars. Some sockets come with a hex bottom to be used with a combination wrench.

- Provides an easy method of removal and installation without damage to the sensor
- Remove and install most popular (O2) Sensors, Oil Sending Units, Vacuum Switches and Injectors
- Made from High-Strength Chrome Molybdenum steel construction
- Use with a ratchet, breaker bar or combination wrench



Package Type: Black blow molded case

Dimensions: 9.25" x 7.25" x 2.15"

Warranty: Limited Lifetime Against Defects

UPC: 047084842003

**Includes/Replacement Parts:**

- 84101CV 1/2" DR x 29mm x 6pt
- 84102CV 3/8" DR x 7/8" (22mm) x 6pt
- 84103CV 1/2" DR x 27mm x 12pt
- 84104CV 3/8" DR x 7/8" (22mm) x 6pt
- 84105CV 1/2" DR x 1-1/6" x 6pt
- 84106CV 1/2" DR x 7/8 (22mm) x 6pt Off
- 84107CV 3/8" DR x 7/8" x 6pt Offset
- 84113CV Blow-Molded Case