



The Harmonic Balancer Installer is used to properly install harmonic balancers or drive pulleys that are pressed on one or two groove pulleys on the crankshaft.

- Safely install most engine harmonic balancer and pulleys without damaging the balancers or crankshaft ends
- Contains twelve thread adapters to fit more applications than other brands.
- Metric and SAE bolts and adapters service most engines
- Black oxide and zinc finish to resist rust

Package Type: Blow Molded Case

Dimensions: 12" x 6" x 2.5"

Warranty: Lifetime vs. Mfg Defect

UPC: 047084388006

**38800**

## ***Harmonic Balancer Installer***



Sizes included:

M10 x 1.5, M12 x 1.5, M12 x 1.75, M14 x 1.5, M14 x 2, M16 x 1.5, M16 x 2, 7/16 - 20, 1/2 - 20, 9/16 - 18, 5/8 - 18, 3/4 - 16