

Flex head offers essential clearance for removal or installation of oxygen sensors awkwardly positioned or when proper leverage is needed around the exhaust pipe.

- Design allows easier access and more torque for removing stubborn sensors
- 6-point
- Designed for all oxygen sensors with 7/8" hex
- Incorporates a harness pass-thru in socket
- Offset design allows for more room and leverage in confined areas


Package Type: Hangtag

Dimensions: 13" x 1.75" x 2"

Warranty: Limited Lifetime Against Defects

UPC: 047084008430

Applications: Ford® 4.6L & 5.4L engines and knock sensors used on mid-sized trucks, SUVs, and vans

**843**

## ***Oxygen Sensor Wrench***

